

Product Introduction

This is one of the first products to offer both a working pen, and a very effective built in video recorder. This durable constructed Digital Video Recorder (DVR) pen allows you to write smoothly, as well as record videos. It uses a built-in rechargeable battery. Once you have recorded a video, connect the pen into a standard USB port to download or watch your videos.

Charging.

- a) **Charging:** The DVR pen charges through either your computer, or through an AC charger (included). When charging the yellow LED light will blink, once fully charged you will see a solid yellow LED light. Inside this device is a rechargeable Lithium battery.

Hint: It's recommend that you deplete the battery completely before recharging after initial use.

Instructions.

- a) **Turning on and Recording:** Press the button, atop the pen, until the yellow LED light comes on; this will indicate that the pen is initializing. Once yellow LED light is shown you may push the button again until the LED turns blue, this means that the recording process has begun. The Camera lens is in a pin hole above the pen's pocket clip. Always face the clip side of the pen towards the subject you want to record.
- b) **Recording:** Recording should be done in a well lit room. For best results keep the pen at least 20 inches from what you are recording.
- c) **Stop Recoding:** While in the recording mode, press the button and release, the indication light will turn from blue to yellow. The unit will shut off automatically after a minute in this mode.
- d) **Continue Recording:** While in the standby mode, with the yellow LED showing, simply press the button until the LED light turns blue.
- e) **Turning Off:** When the LED is blue or yellow, press and hold the button until the LED shuts off. When the LED light is off, the DVR Pen is off.
- f) **PC connection:** To connect the pen to your computer, simply plug the back end of the pen into your computer, and wait. Make sure that the yellow LED light is on, meaning the pen is in standby mode. Your computer will then automatically recognize the pen as a "removable disk", and this can be accessed through "My Computer". Your recordings will be saved in the Movie/Record folders.

Hint: Please be patient while your OS searches its database for the correct drivers. If your system has still not recognized the device disconnect and then reconnect it. Also please install necessary codec's from included CD to ensure your videos are playable.

- g) **Reset:** If the pen ever crashes, there is a master reset button to fix it. The reset button can be found directly underneath the LED light indicator. To use the Reset button please use a non-metallic tool to push the reset button down.

Specifications

- **Camera Sensor:** 640 x 480 pixels
- **Video Format:** 352x288 AVI
- **Supports:** Windows ME/2000/XP/Vista Os/Linux
- **Working Time:** Lithium Battery can keep working for 3 hours
- **Battery Type:** High Capacity Polymer Li-ion Battery
- **Charge Voltage:** DC-5V
- **USB Type:** USB 2.0 standard port
- **Software Version:** V2.61
-

Software Codec:

Remarks

Please follow your states laws while using this product. We are not responsible for illegal use of product.

Miscellaneous

- **More Details on CD.**
- **Please contact manufacturer for any questions not answered in this manual.**

AC Adaptors are available for \$10.00 plus S&H by calling 1 800 998 7771(orders only)